

1stMILE Ingenico USB Driver Installation

This document describes the installation steps for the Ingenico USB driver.

Notices


- The installer automatically uninstalls the old Windows driver and the TeliumUsbPortUpdater tool.
- The user must have administrator-level access to install or uninstall the driver.
- The installer will uninstall all previous versions of the drivers.
- This operation may take some time to complete.

Installation

1. Run the IngenicoUSBDrivers_3.28_setup_SIGNED.exe executable.
2. Click **Next >** to start the installation process



3. Click **Next >** to accept the default destination:



4. Check the Force COM Port Feature checkbox and enter **19** in the Connection Order field to force using COM Port 19. Click **Next >**.

Ingenico USB Drivers 3.28 Setup

Usb Driver parameters
This page allows to set parameters used by USB Driver.

Force COM Port Feature enabled

Select by Product ID

| Product ID (PID) | Virtual COM Port (decimal range 1-256) |
|----------------------|--|
| <input type="text"/> | <input type="text"/> |


Select by Connection Order (Enter decimal Value of COM port)

| | | | | |
|---------------------------------|----------------------|----------------------|----------------------|----------------------|
| <input type="text" value="19"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |
|---------------------------------|----------------------|----------------------|----------------------|----------------------|


Ingenico Group - Smart Terminals

< Back **Next >** Cancel


5. Click **Next >** to uninstall the Microsoft USB driver (usbser).



6. Click **Install** to accept the default Start Menu Folder.



7. Allow the installation to complete.
8. Click **Finish** to close the installer once the installation is complete.



All trademarks, product names, company names, and logos cited herein are the property of their respective owners.